


FAN COIL - MODEL IDENTIFICATION SYSTEM



MODEL	
AH	HORIZONTAL AIR HANDLER
AV	VERTICAL AIR HANDLER
DR	DESIGNER-RISER VERTICAL STACK
ER	EASY-RISER VERTICAL STACK
LH	HORIZONTAL
MH	MINI-HORIZONTAL
LV	VERTICAL
LS	LOW-SILHOUETTE VERTICAL
HIGH-PERFORMANCE	
CH	CASED HORIZONTAL
HL	LOW-PROFILE HORIZONTAL
HH	HORIZONTAL
CV	CASED VERTICAL

CABINET	
B	BASIC
D	DELUXE
E	FLUSH BOTTOM-RETURN AND SUPPLY
F	FRONT-RETURN / TOP-SUPPLY (CV)
F	FLUSH
F	FRONT-DISCHARGE (LS / LV)
G	REAR-RETURN / BOTTOM-SUPPLY (CV/AV)
H	HEAT ONLY (CV)
J	DELUXE FRONT-RETURN / TOP-SUPPLY (CV)
K	BASIC FRONT-RETURN / TOP-SUPPLY (CV)
L	TOP-RETURN / BOTTOM SUPPLY (CV)
M	MASTER (DR / ER)
M	MODULAR (LV)
N	DELUXE MASTER (ER)
O	HEAT ONLY DELUXE (CV)
Q	BOTTOM RETURN-AIR PLENUM (LH / HL / HH)
Q	REAR-RETURN / BOTTOM-SUPPLY DELUXE (CV)
R	FRONT-RETURN / TOP-SUPPLY DELUXE (CV)
R	RECESSED (LS / LV)
R	REAR RETURN-AIR PLENUM (LH / HL / HH)
S	SLAVE (DR / ER), SLOPE TOP (LV)
S	FRONT SUPPLY / FRONT RETURN (CV)
T	DELUXE SLAVE (ER)
W	WRAP SLOPE (LV)

HAND CONNECTION	
D	REAR
E	OPPOSITE END
L	LEFT
R	RIGHT
T	TOP